

March 2026

Sri Mahalingeswara ITI

Answer Key

Duration: 30 Mins**Total Marks: 2****Q.ID: ITISKILL7072V2**

1. Which condition the mechanical zero error occur in panel meters?

- A) At load connected condition B) At load connected condition
C) At normal condition D) At voltage connected condition

Answer: C) At normal condition

2. How the mechanical zero error of panel meter is corrected?

- A) Keeping the meter in vertical position B) By replacing moving coil
C) By replacing moving coil D) By replacing pointer

Answer: B) By replacing moving coil